


## IT \_\_-E0806-\_\_\_\_\_

## **1** EXTERNAL DIMENSION



## 2 LOGIC

PIN#	1	2	3	4	5	6	7	8	9	10	11	12	13	14
SYM	COM	1E	1D	1C	DP1	2E	2D	2C	DP2	COM	3E	3D	3C	DP3
PIN#	15	16	17	18	19	20	21	22	23	24	25	26	27	28
SYM	4E	4D	4C	DP4	5E	5D	5C	DP5	6E	6D	6C	DP6	7E	7D
PIN#	29	30	31	32	33	34	35	36	37	38	39	40	41	42
SYM	7C	DP7	8E	8D	SC 28	8B	8A	8F	8G	7B	7A	7F	7G	COL3
PIN#	43	44	45	46	47	48	49	50	51	52	53	54	55	56
SYM	6B	6A	6F	6G	5B	5A	5F	5G	COL2	4B	4A	4F	4G	3B
PIN#	57	58	59	60	61	62	63	64	65	66	67	68	•	
SYM	3A	3F	3G	COL1	2B	2A	2F	2G	1B	1A	1F	1G	•	